





OIL FILTER

Prevent dirt particles from entering the engine compartment. The main function is to filter all kinds of impurities from the oil.



FUEL FILTER

Filter impurities, avoid clogging, protect other components, engine stability, and improve vehicle safety.



AIR FILTER

Component that is responsible for filtering the air into the engine and preventing dust and debris from entering the engine.

Weichai Genuine Parts, There Is A Difference

Ensure your equipment runs at its best by giving your filter elements the proactive care they need every 250 hours.

Regular maintenance ensures smooth operations, boosts efficiency, and prevents costly breakdowns.

Keep your equipment at its peak performance!



PT. WEICHAI INDONESIA UTAMA

Ruko Sedayu Square Blok J No.01-02, Jalan Outer Ringroad Lingkar Luar, Kel. Cengkareng Barat, Kec. Cengkareng, Kota Adm. Jakarta Barat, Provinsi DKI Jakarta 11730

BATAM **JAKARTA**

JAKARTA JAKARTA JAKARTA JAKARTA

PT WEICHAI UTAMA MANDIRI PT JARUM MAS INDONESIA PT DELTA POWER 88 PT CITA BAJA TRAKTOR PT MITRA WEITEK MAKMUR PT TRAKTOR GEMILANG PERKASA (021) 56982888 (021) 56970778 (021) 3852961 (021) 22305348 (021) 54332774